



**Tips:**  
Cut the food into slices, and arrange them in stacks for cutting again into shreds.



## ◆ INSTALLATION INSTRUCTIONS



1. Fix the mounting base to the cutting board with screws and a Phillips screwdriver.



2. Connect the leg and the trough with hex socket head screws and an Allen key.



3. Insert the lower part of the leg into the mounting base and connect them with the triangle bolt.

## ◆ OPERATION INSTRUCTIONS

1. Thickness adjustment: rotate the thickness adjustment knob clockwise to get thicker slices, rotate the knob counterclockwise to get thinner slices.



2. Pull the push rod and put the food.



3. Rotate the handle clockwise for slicing.



4. Push to remove the lock pin after finishing cutting.



5. Remove the blade plate after removing the lock pin.



6. Rinse the whole blade plate. Easy to clean.



## ◆ OPERATION INSTRUCTIONS



1  
Thickness adjustment: rotate the thickness adjustment knob clockwise to get thicker slices; rotate the knob counterclockwise to get thinner slices.



2  
Pull the push rod and put the food.



3  
Rotate the handle clockwise for slicing.



4  
Push to remove the lock pin after finishing cutting.



5  
Remove the blade plate after removing the lock pin.



6  
Rinse the whole blade plate. Easy to clean.

# SLICER

New design with three troughs.  
Applicable to both soft and hard food.

